

# Visionary

## VIEWPACK

**The Visionary Viewpack** has been designed with a multiple strap system to fit as wide a range of tripods as possible.

Versatile backpack designed to carry a tripod with camera, scope or binoculars mounted.

Featuring:

- 8 contact points for secure installation
- Large quick release accessory pouch
- Secondary zipped pocket and draw string pouch.



**1**

Fully extend your tripod legs and pull them apart. For ease of installation detach the accessory pouch.



**2**

Present the Viewpack to the top, and between two of the open tripod legs. Shoulder straps facing outwards, away from the tripod legs.



**3**

The first buckled strap at the top (narrow end) of the Viewpack should be fastened securely around the base of the tripod head.



**4**

The second buckled strap, positioned slightly lower than the first, should be fastened around the centre column of the tripod.



**5**

There are 3 pairs of Velcro straps at either side of the Viewpack. These should be fastened around the top section of the tripod legs.



**6**

Finally, adjust the shoulder and waist straps to fit the user.

